



Manual Leakage Water Measurement

Weir in U- or V-form (or in combination)
with drain tube, complete in stainless steel



Fix mounted scale to read the quantity of leakage water
(for example in mm, L/min or L/sec)

