



Manual Leakage Water Measurement

With removable weir (for cleaning) in U- or V-form
(or in combination), complete in stainless steel



Fix mounted scale to read the quantity of leakage water
(for example in mm, L/min oder L/sec)

